


## PENTAIR PERISTALTIC DOSING PUMP



# PENTAIR PERISTALTIC DOSING PUMP

## Replacement Parts

No.	Part No.	Description	Part No. Includes*
1	H-D-PLUNGER	Suction Plunger with level control	1
2	RDROLL	Roll holder	1
3	RDPETUBE	Tube PE 4m.	1
4	RDTUBSAN	Tubing Santo 3x7 with 4x6 connection	1
5	RDVLV1	Injection Valve	1

\* PART NUMBER INCLUDES REQUIRED QUANTITY PER PRODUCT